

SL3[®] FLOATING Turbo Dressing Instructions

In order to get the best results, the new SL3[®] FLOATING Turbo needs to be properly dressed before first use.

1. After mounting the red SL3[®] adapter on an appropriate grinder/polisher, firmly attach the Floating Turbo to the 3" - Center Hub, Hook & Loop backer and lock the backer into the red adapter.
2. Run the turbo, with water, against some concrete or the backside of a scrap of granite until the resin surface shine has been removed and the diamonds are exposed.
3. While the grinder is running, roll the abrasive up to round over the sharp outer edge of the pad. This step will need to be repeated as the pad wears down. Failure to round the edge will create half-moon scratches in the finished work piece.
4. Your new SL3[®] FLOATING turbo is ready for use.